



K24




1. Freeflow Insert
2. Cap
3. Centre Screw
4. Flip/Coin Captive Plug
5. Upper Body
6. Foam Washer
7. Rubber Washer
8. Lower Body
9. Rubber Washer (US Only)
10. Tube (US Only)
11. Nut (US Only)


K25




1. Centre Screw
2. Clicker Plug
3. Upper Body
4. Foam Washer
5. Runner Washer
6. Lower Body
7. Rubber Washer (US Only)
8. Tube (US Only)
9. Nut (US Only)




1



2



3



4(US Only)

